

Farber: Getz Lab II (Mac / Media Production Classroom)

(TEC classroom – level B)

Lab II utilizes a ceiling-mounted projector, focused on a wall-mounted screen.

Displaying computer & video sources

1. Use the black, System Control pop up on top of the Instructor Station. If the pop up is closed, push **DOWN** on the cover to access the pop-up controls. The station rolls about 4' in the instructor area! Roll back when done, directly next to the table!
2. Press the **PROJ ON** button. Projector will take 45 seconds to warm up. No controls will function during warm up.
3. **After the warm up period, you MUST select your preferred input using the appropriate buttons. (Buttons illuminate when active.) There is a seven (7) second lock out period after input selection, when you cannot jump to another source. Just re-select your source after the 7 seconds.**
 - **PC/LAPTOP** will display the MAC, installed on the table next to the station.
 - **Laptop** connections are provided via a VGA cable with an attached audio connector, accessed thru a circular grommet opening. *The system will auto-detect, and switch to the laptop when properly connected.* A power plug is available in the control pop up. **MAC users must provide their own MAC adapter.**
 - **DVD/S-VIDEO** selects the DVD player, inside the Instructor Station. *Audio CDs can be played in the DVD player, but also in the MAC or your laptop.*
 - **VHS/VIDEO** selects the *MINI-DV/VHS* player in the same location.
 - You may operate the video devices using controls on each unit, or with their remotes controls.
 - **EXTERNAL** video/audio sources may be presented (such as a camcorder). Plug your video cable into one of the inputs @ the Media Center section of the control pop up. *System will auto-detect & display.*
3. The **AUTOIMAGE** button will let you adjust the projector to attempt proper sync with your laptop. **We recommend XGA resolution (1024x768) for best results, though the projector will adapt to slightly higher and wide format resolutions.**

BEST PRACTICE TIP: before powering on or opening up your laptop, connect the laptop cable and select the **PC/LAPTOP** input on the control panel. At this point, power on and open up your laptop. ***Refer to our "laptop display tips" for more info.***
4. The **AV MUTE** button blacks out video and audio. Hit it again to return to your presentation.
5. **PC LOGON:** ****Use your UNET name and password, in the USERS domain. **** *Going wireless? If not in the UNET USERS domain, you may logon as a "guest user" with your email address. ***

Audio Controls

1. Simply hit the **AUDIO ^** and **AUDIO v** buttons to control your levels.
2. The **AUDIO MUTE** button will mute all sound levels. Just hit it again to regain sound.



When Finished

1. Press the **PROJ OFF** button and confirm that the projector shuts down to conserve energy and save lamp life!
2. Return or neaten up any cables/items to help maintain the facility.
3. Close the pop up control station.

